

**Getting started: Franklin T9**


**Buttons and Icons:**

There's a lot you can do with your new device, so here's a quick glance of some basic items to get you started.

**Buttons**



1. **Power/Menu Button** – Turn on/off T9. Shows device menu and information

Button Operation	
	Actions
	<b>Turn On</b> Press and hold the button for 3 seconds.
	<b>Turn Off</b> Press and hold the button until "Goodbye" message appears.
	<b>Display Wake-Up</b> When the display is off (sleep mode), the first quick press of the button wakes up the display.
	<b>Info Display</b> When the display is on, press the button quickly to go through the device menu and information.

**Device Display**




**First Time Use:**


When you first turn on your new device, you might see a setup wizard to help get you started.


Look at the steps below to walk through the setup process. You can use your T9 as a wireless mobile hotspot to connect to a total of 8 Wi-Fi capable devices to the mobile broadband network.

**Wi-Fi Name (SSID) and Password:**

You can find your Wi-Fi Name and Password any time you need. Just press the power/menu button shortly when the display is on.



Press  quickly      Wi-Fi Name display

Press  quickly      Password display

1. Power on your hotspot

Press  quickly

2. Open the Wi-Fi application or controls on your laptop or Wi-Fi capable device that you want to connect to your T9. Then find your T9's Wi-Fi name.
3. Click **Connect** and enter the Password when prompted
4. Open your browser and you are good to go!

**TroubleShooting:**

- For Basic troubleshooting please contact T-Mobile @ 1-800-375-1126. You will need the phone number located on the back of your device under the battery cover.
- For Unresolved support please contact **XXXXXXXXXXXXXXXXXXXXXXX**

**Cómo empezar: Franklin T9**

**Botones e Iconos:**

Hay mucho que puedes hacer con tu nuevo dispositivo, así que aquí tienes un vistazo rápido de algunos elementos básicos para empezar.

## Botones



1. **Power/Menu Button** – Turn on/off T9. Shows device menu and information

### Button Operation

	Operations	Actions
	Turn On	Press and hold the button for 3 seconds.
	Turn Off	Press and hold the button until "Goodbye" message appears.
	Display Wake-Up	When the display is off (sleep mode), the first quick press of the button wakes up the display.
	Info Display	When the display is on, press the button quickly to go through the device menu and information.

## Device Display




### Uso por Primera Vez:

La primera vez que enciendas el nuevo dispositivo, es posible que veas un asistente de configuración para ayudarte a empezar.


Mira los pasos a continuación para recorrer el proceso de configuración. Puede utilizar su T9 como punto de acceso móvil inalámbrico para conectarse a un total de 8 dispositivos compatibles con Wi-Fi a la red de banda ancha móvil.

### Nombre de Wi-Fi (SSID) y Contraseña:

Puede encontrar su nombre y contraseña de Wi-Fi en cualquier momento que lo necesite. Simplemente presione el botón de encendido/menú en breve cuando la pantalla esté encendida.



Press quickly      Wi-Fi Name display



Press quickly      Password display

1. Encienda su punto de acceso

Press quickly

2. Abra la aplicación Wi-Fi o los controles en su computadora portátil o dispositivo compatible con Wi-Fi que desea conectar a su T9. A continuación, busque el nombre Wi-Fi de su T9.
3. Haga clic en **Conectar** e introduzca la Contraseña cuando se le solicite
4. Abra su navegador y ya está listo

### TroubleShooting:

- For Basic troubleshooting please contact T-Mobile @ 1-800-375-1126. You will need the phone number located on the back of your device under the battery cover.
- For Unresolved support please contact: **XXXXXXXXXXXXXXXXXX**